


TransSECS for an OPCUA Server

Using Servers TransSECS to Create an OPCUA SECS/GEM Tool Interface




Installing TransSECS




Double click on the installer and click **Next** when prompted. Once installed, start the TransSECS Builder application (MIStudioSuite/TransSECS/Builder/TransSECS.exe)




The example GEMTool will be loaded when you start the



Select the type of server for deployment




Press the Hammer/Star button to build the project






When the "Compilation" popup closes the build is complete. This may take a minute or so.






After the code is generated the server code for the tool will be in the Projects/GEMTool/OPCUA directory.



Everything you need to run on Windows is in this directory. For Linux systems you will need install rxtxSerial on the system and make appropriate changes to the run.sh file.

You may need to edit the path to the jre in run.bat if you move the deployment location.

Run the server with the run.bat file.





Run the SECS/GEM Interface as an OPCUA Server

```
C:\WINDOWS\system32\cmd.exe
C:\Users\Public\ErgoTech\TransSECSServersTrial\Projects\GEMTool\OPCUA>java deploy.GEMTool.EquipmentController
Started tool GEMTool on port 5010 device id 1
2019-03-09 10:53:21.291 [createFolderNode( gemtool:gemtool]2019-03-09 10:53:21.291
2019-03-09 10:53:21.291 [createFolderNode( vids:gemtool/vids]2019-03-09 10:53:21.291
2019-03-09 10:53:21.306 [creatingNode( s5f1replybit:com.ergotech.secs.gem.GemECID periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [createFolderNode( confiquration:qemtool/confiquration]2019-03-09 10:53:21.306
019-03-09 10:53:21.306 [creatingNode( port:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( deviceid:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet1:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet2:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet3:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet4:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet5:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet6:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet7:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet8:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( baudrate:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
019-03-09 10:53:21.306 [creatingNode( persistencefilename:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [createFolderNode( hostcommandstart:gemtool/hostcommandstart]2019-03-09 10:53:21.306
2019-03-09 10:53:21.322 [creatingNode( cpvalue:deploy.GEMTool.HostCommandSTART periodic false]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [vib.utils.VIBOPC > setValueObject( PrimaryOutPort:O ) setValueObject="RecipeName" )]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode( responsestatus:deploy.GEMTool.HostCommandSTART periodic false]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode( errorstatus:deploy.GEMTool.HostCommandSTART periodic false]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode( command:deploy.GEMTool.HostCommandSTART periodic false]2019-03-09 10:53:21.322
019-03-09 10:53:21.322 [vib.utils.VIBOPC > setValueObject( PrimaryOutPort:3 ) setValueObject="START" )]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode( goodstatus:deploy.GEMTool.HostCommandSTART periodic false]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode( spoolfulltime:com.ergotech.secs.gem.GemSVID periodic false]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [vib.utils.VIBOPC > setValueObject( PrimaryOutPort:0 ) setValueObject="0" )]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode( spoolcounttotal:com.ergotech.secs.d
                                                                          When you run the generated
2019-03-09 10:53:21.322 [vib.utils.VIBOPC > setValueObject( PrimaryOutPort
<u>2019-03-09 10:53:2</u>1.337 [creatingNode( clock:com.ergotech.secs.gem.GemCLOC
                                                                          run.bat, the tool's SECS/GEM will
2019-03-09 10:53:21.337 [vib.utils.VIBOPC > setValueObject( PrimaryOutPort
                                                                          be running on Port 5010 and
                                                                          Device ID 1 as an OPCUA server.
```




Run the SECS/GEM Interface as an OPCUA Server

```
C:\WINDOWS\system32\cmd.exe
C:\Users\Public\ErgoTech\TransSECSServersTrial\Projects\GEMTool\OPCUA>java deploy.GEMTool.EquipmentController
Started tool GEMTool on port 5010 device id 1
2019-03-09 10:53:21.291 [createFolderNode( gemtool:gemtool]2019-03-09 10:53:21.291
2019-03-09 10:53:21.291 [createFolderNode( vids:gemtool/vids]2019-03-09 10:53:21.291
2019-03-09 10:53:21.306 [creatingNode( s5f1replybit:com.ergotech.secs.gem.GemECID periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [createFolderNode( confiquration:qemtool/confiquration]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( port:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( deviceid:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet1:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet2:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet3:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet4:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet5:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet6:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet7:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( passivet8:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( baudrate:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [creatingNode( persistencefilename:deploy.GEMTool.EquipmentController$1 periodic false]2019-03-09 10:53:21.306
2019-03-09 10:53:21.306 [createFolderNode( hostcommandstart:gemtool/hostcommandstart]2019-03-09 10:53:21.306
2019-03-09 10:53:21.322 [creatingNode( cpvalue:deploy.GEMTool.HostCommandSTART periodic false]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [vib.utils.VIBOPC > setValueObject( PrimaryOutPort:O ) setValueObject="RecipeName" )]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode/ responsestatus:deplov.GEMTool.HostCommandSTART periodic false]2019-03-09 10:53:21.322
<u> 2019-03-09 10:53:21.322 [creating</u>Node( errorstatus:deploy.GEMTool.HostCommandSTART periodic false]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode( command:deploy.GEMTool.HostCommandSTART periodic false]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [vib.utils.VIBOPC > setValueObject( PrimaryOutPort:3 ) setValueObject="START" )]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode( goodstatus:deploy.GEMTool.HostCommandSTART periodic false]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode( spoolfulltime:com.ergotech.secs.gem.GemSVID periodic false]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [vib.utils.VIBOPC > setValueObject( PrimaryOutPort:0 ) setValueObject="0" )]2019-03-09 10:53:21.322
2019-03-09 10:53:21.322 [creatingNode( spoolcounttotal<u>:com.ergotech.secs.gem.GemSVID neriodic false12019-03-09</u> 10:53:21.322
The SECS/GEM OPCUA Server endpoint URL is
2019-03-09 10:53:21.337 [vib.utils.VIBOPC > setValueOk
                                                     opc.tcp://127.0.0.1:12686/MIXOPCServer
```



Test the SECS/GEM Interface with TransSECS GEMHost using TransSECSTest.exe




This starts TransSECS with the GEMHost project which runs as a Host to test the tool interface.

Note: If the ExtendedHost is loaded when TransSECSTest is started, use the File menu to load the GEMHost project.




Run TransSECS as a test host

Set to LIVE mode before building the GEMHost project



Run TransSECS Test as a host

This arrow shows that the host is running




Select a primary (outgoing) message and Press "Send Message" button to send it

Messages sent and received will be shown in the Messages panel (when a message is selected)

Send an S1F3 test message to the tool


Select the S1F3 Message.



Change the SVID you want to request

Press the Send Message button to send the message to the tool

The sent message and its reply will appear in the Message Panel





Test an OPCUA Client Connection


This example will use the UAExpert Reference Client to test the OPCUA SECS/GEM Server.

https://www.unified-automation.com/products/development-tools/uaexpert.html

The steps are basically the same for any OPCUA Client:


- 1) Run the OPCUA Client
- 2) configure a connection to the SECS/GEM OPCUA Server
- 3) connect to the SECS/GEM OPCUA Server
- 4) resolve security certificate issues

Start UAExpert and Add a new OPCUA Server





Configure the Server in UAExpert




Name the OPCUA Server connection

Enter the Endpoint URL for the SECS/GEM OPCUA Server

Select the Security
Policy and Message
Security Mode. All
choices, including
NONE is valid for the
SECS/GEM OPCUA
Server.


Connect to the OPCUA Server





OPCUA Certificates


OPCUA requires certificates for authentication. Note: No certificate is required for the security policy NONE and message security mode NONE in the client setup.






UAExpert Certificate Exchange

During the first connection to the OPCUA Server the server's security certificate will be imported by UAExpert.




UAExpert Certificate Exchange






There is one more certificate related

UAExpert Certificate Exchange




OPCUA Certificate Exchange


The UAExpert client certificate has been installed in the OPCUA server directory as "rejected" because it needs approval to be trusted. Browse to the OPCUA server security "rejected" folder to find this certificate.




UAExpert Successful Connection














Test the WaferCount Value in the Host



















Notes on OPCUA Servers: JSON List Formats

List elements are JSON formatted, such as { "values": []}

For example, the recipe list for an S7F20 might look like: { "values": ["recipe1", "recipe2", "recipe3", "recipe4"] }

There are more things you can do with the JSON format for the lists, including making lists of lists and specifying the SECS format for the data in the list.



Notes on OPCUA Servers: JSON List Formats

```
If a specific type is required, it can be specified if needed. For example for the recipe list, the data is ASCII, type 20: { "values": [ "recipe1", "recipe2", "recipe3", "recipe4"], type: "20" }
```

type is defined by the SECS Standard:

```
00 - List
```

10 - Binary (can be an array)

11 - Boolean

20 - String

30 - 8 byte floating point

34 - 4 byte floating point

40, 41, 42, 44 - 8, 1,2,4 byte signed integers

50, 51, 52, 54 - 4 byte signed integer



Notes on OPCUA Servers: JSON List Formats

Each element of the array can have a different type in this format (this might be useful in some message replies with different data types):



Notes on Tool OPCUA Servers: Triggering Events with DVVALs

Events can be triggered with a list of DVVALS, so if you need to do this you can define the list, then use this as the trigger input to the CEID. If you are using DVVALs in your project you would associate the DVVALS when you define your CEID.

DVVALS as a JSON String sent to the trigger of a CEID:

```
{ "values":[
     { dvid:WaferCount, dvval:15 },
     { dvid:23456, dvval:\"Hello World\" }
] }
```

You can specify any VID with either its name (for example WaferCount), or its vid number (for example 23456) as the above example demonstrates.



Notes on OPCUA Servers: Host Commands

If you publish the whole host command, the structure is a list (with the host command), then the list elements for the parameters for the command.

It may look something like:

```
{ "values": [ { "value": "PP-SELECT", type: "20 } } { "values": [ { "values": [ LOTID ], type: "20 } { "values": [ { "value": "CHAMBER", type: "20 } } { "value": "1", type: "51 } } ] } { "values": [ PPID ], type: "20 } ] } ]
```



Notes on OPCUA Servers: vibopc.properties

The vibopc.properties file has some settings which control some aspects of the OPCUA runtime. This file is located in the OPCUA deployment directory.

VIBOPC.NoMethodSupport

This defaults to false. If set to true opcua methods are generated for operations such as sending messages. Some OPCUA clients do not support methods.

VIBOPC.UnderscoreCreatePaths

This defaults to true. This allows you to define vid names with underscores which will generate a tree structure for the vids. For example a vid "robot_xaxis" will generate a tag structure /toolname/vids/robot/xaxis".



That's it.

Now you're ready to program your OPCUA Client application to complete integration of the SECS/GEM interface. You should update your tool data values (SVIDs) as they change and can trigger alarms (ALIDs) and events (CEIDs) and send and receive messages as needed. You may need to handle host commands and send the host command replies from your OPCUA client using the sendMessage tags. More host command message handling can be added, and also there are options for manually handling recipe messages, or you can set up simple automatic recipe handling.